



Installation Instruction:

Picture on the left shows how the baffle should position inside the oil pan.

The provided washer should be installed to the location circled in Yellow to fill the gap between the oil pan and the windage tray.



Reinstall all the bolts and windage for final assembly.

Picture on the left shows how the oil pan should look like after the final assembly.



Special Installation Note:

The area highlighted in BLACK on the baffle (circled in RED in the picture) may require grinding for clearance for some NC 2.0 oil pan.

Recommend to do a test fitting before final assembly to see if grinding for clearance is necessary.

***** DO NOT grind the oil pan *****